

## Operating Instructions

---

CE



ZI 1293 / ...

Multi-Zone Control Unit

**Contents**

1.	Introduction	3
2.	Special features	3
3.	Technical data	3
4.	Range of the control units ZI 1293/...	4
5.	Electrical connection	5
5.1	Pin diagram for ZI 1293/...	5
5.2	Assignments of Zones - Plug	5
6.	Start-up	6
6.1	Functions of the keys and displays	6
7.	Description of the displays and keys	7
7.1	Description of keys	7
7.2	Alarm displays	7
8.	Settings	8
8.1	Activating control zones	8
8.2	Deactivating control zones	8
8.3	Set value settings	9
8.4	Changing of settings	9
8.5	Selector mode	10
8.6	Reset of factory settings	11
8.7	Soft Start	11
9.	Menu points	12
10.	Connector pin assignment	13
11.	Replacing fuses	14
12.	Safety instructions	15

## 1. Introduction

The HASCO multi-zone controller ZI 1293 / ... provides clear display of all SET and ACTUAL values. These are divided into groups of 6 zones.

## 2. Special Features

- 6 unit sizes are offered : 6, 12, 18, 24, 30 and 36 control circuits.
- Modular construction providing 3200 W per control circuit.
- Programmable soft start.
- Standard alarm input and output.
- Manual or automatic change to selector mode.
- Programmable setting for short-term temperature increase.
- Temperature stand by mode
- Performance display in Ampere and % selector ratio.
- Thermocouple monitoring
- Synchronized heat-up

**CE** The control unit ZI 1293 / ... corresponds to the important protection requirements in agreement with the EU guidelines.  
The Control unit ZI 1293 / ... also corresponds to the important protection requirements following the UL (USA) and CSA (Canada) guidelines.

## 3. Technical data

	ZI 1293/6/...	ZI 1293/12/...	ZI 1293/18/...	ZI 1293/24/...	ZI 1293/30/...	ZI 1293/36/...
Outside dimensions (W x H x D)	350 x 200 x 400		350 x 380 x 400			
Device fuse protection	32 A / Phase					
Connected voltage	3 phases 120VAC / 60 Hz, L1-L3 = black / white / red					
Power output	3200 W / zone (max. 19 kW)					
Thermocouple	Fe-Cu Ni, Typ J					
Operating range	122 ... 932°F					
Control accuracy	± 2 °F (at optimum conditions)					
Ambient temperature	50 ... 104°F					
Alarm control outputs	2 Switch inputs					
Alarm outputs	2 relay changeover contacts max. 33 VAC / 70 VDC					
Power fuse	FF 16 / 500					
Degree of protection	IP 21 (EN 60529)					

#### 4. Range of the control units ZI 1293/...

**ZI 1293/6/16**  
6 Control circuits

**ZI 1293/12/16**  
12 Control circuits



**ZI 1293/18/16**  
18 Control circuits

**ZI 1293/24/16**  
24 Control circuits

**ZI 1293/30/16**  
30 Control circuits

**ZI 1293/36/16**  
36 Control circuits



## 5. Electrical connection


The power and thermocouple linkage between mold and control unit ZI 1293/... is made with a separate power cable ZI 1222/... and TC cable ZI 1223/...

The following must be adhered to when using all ZI 1293/... temperature control zones:



**The maximum power input of 19 kW must not be exceeded!**

### 5.1 Pin diagram for ZI 1293/... (Examples)

e.g. ZI 1293/6x16



e.g. ZI 1293/12x16



Allocation of pin connection according to DIN 16765

### 5.2 Assignments of Zones - Plug

Load

TC

Zone	PIN
1, 13, 25	1 / 13
2, 14, 26	2 / 14
3, 15, 27	3 / 15
4, 16, 28	4 / 16
5, 17, 29	5 / 17
6, 18, 30	6 / 18
7, 19, 31	7 / 19
8, 20, 32	8 / 20
9, 21, 33	9 / 21
10, 22, 34	10 / 22
11, 23, 35	11 / 23
12, 24, 36	12 / 24

Zone	PIN
1, 13, 25	1+ / 13-
2, 14, 26	2+ / 14-
3, 15, 27	3+ / 15-
4, 16, 28	4+ / 16-
5, 17, 29	5+ / 17-
6, 18, 30	6+ / 18-
7, 19, 31	7+ / 19-
8, 20, 32	8+ / 20-
9, 21, 33	9+ / 21-
10, 22, 34	10+ / 22-
11, 23, 35	11+ / 23-
12, 24, 36	12+ / 24-

## 6. Start-up

Connect T/C and power cables to mold. Check with Volt/Ohm meter to make sure power and T/C cables are connect. Plug cables into controllers.

Switch control unit On at the main switch at the back.

Set the set temperature. **Make sure that unused control zones are switched off (see page 8).**

The control unit now heats the mould evenly, moist heating elements are dried out.


During this time, the temperature deviation alarm displays blinks in all active zones.

The temperature in °F is shown in the zone window. In the switched-off control zones the display shows "OFF".

After reaching the set temperature, production can start with the calculated parameters.

If failures occur during start-up, then the cause of the failures can be recognized by the corresponding displays at the individual zones (see page 7).

### 6.1 Function of the keys and displays



## 7. Description of the displays and keys

### 7.1 Discription of keys

Key display lights up when operated (function On).



#### Set value

The set point values appear in the zone windows or "OFF" in the non-active zones.



#### Load current (A) / power regulation ratio (%)

The actual load current (A) / power regulation ratio (%) appears in the active zone windows.



#### Boost function active

Temperature is raised for a short period.  
Same function via external alarm-communication connection-cable.



#### Lowering active

Temperature is permanently lowered.  
Same function via alarm plug.

### 7.2 Alarm displays



#### Thermocouple

Lights up if thermocouple is broken and "- - -" appears in the zone window. If the automatic selector mode (Automode) is active, then the display alternates between "- - -" and "- A -".  
The display blinks up for reverse poling and the room temperature appears in the zone window.



#### Temperature deviation

It is flashing during the heating phase of the soft start ramp.  
In addition, the current load are double-side disconnected for over temperature (max exceeding of set value).










#### Current overload









Lights up when the set maximum current is exceeded (see change set values) or for missing load.  
For current overload the load are double-side disconnected.

## 8 Settings

### 8.1 Activating control zones


Key	Command
	Display
	<b>Display set temperature</b> The set temperatures are displayed in the zone windows or "OFF" in the inactive zone. The key display lights up.
 	<b>Select zone</b> The selected zone number is displayed in the dialog window.
	<b>Confirm zone</b> "TEMP" is displayed in the dialog window, the set values in the zone windows blink to be altered.
	<b>Storing</b> The selected zone is activated.
	<b>Set temperature Off</b> The actual temperatures are displayed in the zone windows or "OFF" in the inactive zones. Key display "Off". Control operation.
	<b>Abort without storing:</b> <b>Abort</b> Goes back one programming step without changing the set values.

### 8.2 Deactivating control zones


Key	Command
	Display
	<b>Display set temperature</b> The set temperatures are displayed in the zone windows or "OFF" is displayed in the inactive zones.
 	<b>Select zone</b> The selected zone number is displayed in the dialog window.
	<b>Confirm zone</b> "TEMP" is displayed in the dialog window, the set point values flashes in the zone windows to be altered.
	<b>Deactivate zone</b> Press key for 3 sec. till "OFF" is displayed in the zone windows.
	<b>Store deactivating</b> Press key again.
	<b>Set temperature Off</b> The actual temperatures are displayed in the zone windows or "OFF" is displayed in the inactive zones. Key display Off. Control operation.
	<b>Abort without storing:</b> <b>Abort</b> Goes back one programming step without changing the set values.



### 8.3 Set value settings



### 8.4 Changing of settings



## 8.5 Selector mode



### CAUTION:

The hotrunner block is not controlled in this operating state and will not switch off for over temperature. Therefore, overheating and destruction of the hotrunner block is possible!

### Key

Display

### Command



### Display set value

The set values appear in the zone windows or "OFF" in the inactive zones. The key display lights up.



### Select zone

Set the desired zone for the actuator operation.

**Manual operation is only possible for individual zones!**



### Confirm zone

"PULS" appears in the dialog window.



### Set load

In percent (P 01... P100 = 1... 100 %).



### Confirm setting

The set value is accepted.



### Set value display Off

The display of the manually operated zone is alternatively "P" for (pulse operation) and the actual current value (for a defective thermocouple "- - -"). In the zone windows without manual operation, the actual values are displayed or "OFF" for the inactive zones.

**The set manual operation is reset by switching off the device at the main switch!**



### Abort without storing:

#### Abort

Goes back one programming step without changing the set values.

## 8.6 Reset of factory settings


Key	Command
	Display
PRG longer than 5 sec.	<b>To change settings</b> Press and hold the "PRG" key for 5 seconds then the dialog window displays "ALL" and zone numbers appear in the zone windows.
△ ▽	<b>To select zone</b> The selected zone number appears in the dialog window and "ALL" is displayed for all zones.
PRG	<b>To confirm zone</b> The first menu point appears in the dialog window. The actual temperatures are displayed in the zone windows or OFF is displayed for the inactive zones.
△ ▽	<b>Select menu point</b> The respective menu point is displayed in the dialog window. Choose PRESET
PRG	<b>Confirm menu point</b> The dialog window display alternates between "PRESET" and "OK?"
PRG	<b>Storing</b> The settings are reset at work.
ESC ①	<b>Exit set mode</b> Dialog display is deleted, the actual temperatures are displayed in the zone windows or OFF in the inactive zones, normal operation.
ESC ①	<b>Abort without storing : Abort</b> Goes back one programming step without changing the set values.

## 8.7 Soft Start

After switching on the controller, the temperature increases to the set soft start temperature of ramp 1 ( $rE = 248^{\circ}F$ ). After reaching this temperature, the dwell time  $r_t$  is activated (for 1 minute). This is permitting any residual moisture in the heating elements to escape.

Ramp 2

The 2nd ramp  $r_2$  starts once the dwell time  $r_t$  has expired for all activated control zones. The temperature then increases to the set value for production run.



## 9. Menu points


Menu points	Display	Settings		Remarks
		At works	Value range	
Over temperature switch point (Ot)	<b>O V T E M P</b>	50 °F	32 ... 122 °F above set value	
Under temperature switch point (Ut)	<b>U N T E M P</b>	50 °F	32 ... 122 °F below set value	
Final temperature ramp 1 (rE)	<b>R M P E N D</b>	248 °F	248 ... 320 °F	
Temperature rise ramp 1 (r1)	<b>R M P T 1</b>	2 °F/4 s	2 °F/10 s ... 2 °F/2 s	
Temperature rise ramp 2 (r2)	<b>R M P T 2</b>	2 °F/2 s	2 °F/10 s ... 2 °F/2 s	
Dwell time of the final temperature ramp 1 (rt)	<b>R M P P S E</b>	2 min.	0 ... 4 min.	
Automatic selector mode	<b>A U T O</b>	0 (Off)	1 = On 0 = Off	(Operating time min 15 minutes!). For active function, after thermocouple break, heating is continued with the average output performance of the past 15 minutes.
Temperature decrease	<b>T E M P D N</b>	122 °F below set value	50 ... 392 °F below set value	
Thermocouple selection type J or type L	<b>T C T Y P</b>	J	J or L	
Temperature unit	<b>U N I T</b>	°F	°F or °C	
Reset of in-plant settings	<b>P R E S E T</b>	-	-	All changed settings could be reset of in-plant settings
Software Version of the Control Card	<b>F W V E R</b>	-	V ...	Shows Software version
Access code / input lock	<b>C O D E</b>	0 (deactivated)	0 - 250	
Deactivate ramp synchronisation	<b>S Y N C</b>	1 (On)	1 = On 0 = Off	
The following functions can be set individually for each zone				
Raising the boost temperature	<b>T E M P U P</b>	68 °F	41 ... 140 °F	
Duration of the boost process	<b>U P T I M E</b>	20 s	0 ... 180 s	
Over current switch point	<b>C U R R</b>	16 A	1 ... 16 A	
Set value limit	<b>T M P M A X</b>	842 °F	122 ... 932 °F	

10. Connector pin assignment

Controller alarm

Alarm output of the controller (potential-free normally open contact)  
Connection from controller to injection molding machine

Alarm outputs    1 = overtemperature  
                      2 = undertemperature




PIN	Description
1	Ö -Alarm 1 (OVTEMP)
2	M-Alarm 1 (OVTEMP)
3	S -Alarm 1 (OVTEMP)
6	S -Alarm 2 (UNTEMP)
7	M-Alarm 2 (UNTEMP)
8	Ö -Alarm 2 (UNTEMP)

Temperature reduction

Alarm output of the injection molding machine  
Connection from injection molding machine to controller

Alarm inputs    1 = temperature reduction  
                      2 = boost



PIN	Description
4 + 5	E1-Reduction
10 + 12	E2-Boost

## 11. Replacing fuses

**Working on the unit may only be carried out by authorized technicians, before opening unplug the unit.**




To change the fuses please open front panel and disconnect plugs.

Pull the concerned control card. Replace of fuses only with a same type!

The control cards are designed for 6 zones in each case, allocation see below.

Assembly in reversed order.

### Allocation zones / control cards



Zone	Card	Fuse	Zone	Card	Fuse
1	1	a + b	19	4	a + b
2	1	c + d	20	4	c + d
3	1	e + f	21	4	e + f
4	1	g + h	22	4	g + h
5	1	i + j	23	4	i + j
6	1	k + l	24	4	k + l
7	2	a + b	25	5	a + b
8	2	c + d	26	5	c + d
9	2	e + f	27	5	e + f
10	2	g + h	28	5	g + h
11	2	i + j	29	5	i + j
12	2	k + l	30	5	k + l
13	3	a + b	31	6	a + b
14	3	c + d	32	6	c + d
15	3	e + f	33	6	e + f
16	3	g + h	34	6	g + h
17	3	i + j	35	6	i + j
18	3	k + l	36	6	k + l



## 12. Safety instructions

- HASCO-connecting cables and connecting housings are to be used for the electrical connections (power and thermocouple connections) between control unit and the mold.  
This will ensure optimum controlling accuracy.
- The control units are matched to the HASCO range of standard elements.  
No guarantee can be given for trouble-free functioning if components of foreign brands are used.
- Connection, repair and maintenance work may only be carried out by trained electrical technicians.
- During work on the control units and the linked cables, devices, machines and tools, all parts must be disconnected from the mains.  
The system must also be safeguarded from being unintentionally turned on again.
- HASCO-connecting cables must be regularly checked for mechanical damage and replaced as necessary.
- The devices must be located such that sufficient ventilation and cooling is available.
- The controllers must be protected from moisture and wet.
- The devices must be applied in a technically meaningful way.
- Unplug the unit when replacing the fuse.
- When changing fuses the plug must be pulled out.
- From a unit size of ZI1293/ 18/ 16 it is recommended to clean the dust filter once a while resp. to replace it depending on operating period and condition.
- Furthermore the cooling ribs of the unit should be checked and if necessary removed from contamination.  
This may only be carried out by authorized service people.